



Innovative Ceramic Corporation

Creative Solutions to Product Identification & Decoration

Inking Stamp Pad With Water Base Inks

Before inking the stamp pad, shake the ink bottle vigorously in a circular movement. With the dispensing cap on the ink bottle, dispense the ink back and forth across the length of the pad. Turn the pad 90° and dispense ink back and forth across the width of the pad. In the beginning the ink will just sit on the pad, if the pad is an un-inked pad (dry pad). As you continual inking the pad in both directions the ink will be absorbed into the pad faster and faster. Once the ink absorption starts to slow down stop inking the pad once you finish reaching the other side of the pad.

After inking the ink pad, there is too much ink on the top surface to be used. The result of using the ink pad soon after inking would produce an over ink image. The ink pad needs time to distribute the ink equally throughout the pad. The best time to re-ink the pad is at the end of the shift so it is ready to go the next day. The minium time to wait after re-inking the pad is three plus hours. Any questions, just call 1-330-385-6515 or email to info@innovativeceramic.com.